


Driver Installation

(For all Tecella products, except for the Pico)


Document Revision 1.0
July 8, 2018

Tecella
97 Chaumont Cir
Foothill Ranch, CA 92610, USA
www.tecella.com
info@tecella.com
+1-714-641-1709
+1-714-641-1569 Fax


1. Double click on "Driver_64bit_4.5.6.exe"




2. Click on "Next"




3. Click on "I Agree"



4. Uncheck everything except "FrontPanel USB Driver".
"FrontPanel USB Driver" is checked by default, and cannot be unchecked.



5. Click on "Install"



6. Click on "Finish" to complete driver installation

